DURAFLAT Customizing

DURAFLAT sections can be easily customized with your company name and phone number.

- * Using 5" paper stencils, arrange company name and phone number.
- * Arrange stencils as desired onto flat section.
- * Using standard white spray paint, spray directly onto stencils until all lettering has been fully covered by paint (be careful of over-spray).



* Carefully, to avoid smearing paint, remove stencils.

